


# **MULTI-MODEL** **SUSPENSION TIGHTENING TORQUE**

When suspension repairs are necessary, tighten the strut assembly, sway bar, and upper and lower control arms with the suspension loaded as shown below.



Tightening suspension components unloaded may cause:

- Ride height concerns
- Bushing damage
- Vehicle pull